## SPECIFICATION SHEET JFW MODEL 50PA-560

HANDOVER TEST SYSTEM

Phone: 317-887-1340 sales@jfwindustries.com

www.jfwindustries.com

JFW Industries, Inc.

Frequency Range 700-3000 MHz

 $4 \times 8$  Handover System Configuration

(see block diagram 092-6344 for attenuator addressing)

(all ports are bi-directional)

(full fan-out i.e. every path has its own attenuator)

(the ADMIN password is located on rear panel)

19 inch rack mount @ 5RU high Enclosure Type

50 Ohms nominal Impedance

Attenuation Range 0-127 dB in 1 dB steps

Startup/Default States Maximum attenuation (see ATTEN STARTUP command)

(configurable) DHCP enabled (see NET command)

4 Ethernet users (see NET USERS command)

Prompts off (see PROMPT command)

**VSWR** 1.7:1 maximum

20 dB nominal @ 700 MHz Insertion Loss

23 dB nominal @ 3000 MHz

± 0.50 dB or 2% typical Attenuation Accuracy

± 0.75 dB or 2% maximum (whichever is greater) (guaranteed monotonic)

Isolation 40 dB minimum (Input to Input)

30 dB minimum (Output to Output)

RF Input Power +20 dBm average

Switching Speed 5 microseconds typical

> (after command is received and processed) (3 milliseconds typical processing time)

AC Supply 100-240 VAC @ 47-63 Hz

> 4 Amp 5x20mm "Slo-Blo" AC fuse Littelfuse #215-004, JFW #025-018

Remote Control Ethernet (DHCP, TCP/IP, 10/100, up to 12 users)

RS-232 (up to 115200 Baud)

Manual Control 20-Button Keypad and LCD display

> (IP Address configurable via keypad) (Net mask configurable via keypad) (Gateway configurable via keypad) (Baud rate configurable via keypad)

## --CONTINUED--

Page 1 of 2 JFW FORM E-7-F REV F

## SPECIFICATION SHEET JFW MODEL 50PA-560 HANDOVER TEST SYSTEM

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

Remote Commands Attenuator Control Commands:

Atten, Set Path, Read Path, Read All Paths, Set Attenuator, Read Attenuator, Set All Attenuators, Read All Attenuators, Read All Extended, Fade Attenuator, Variable Attenuator Handover, Block, Set Block, Read Block, Read All Blocks, Fade Block, Variable Block Handover

System Commands:

Help, Identification, Store, Recall, Pause, Net, Serial, Close, Disconnect, MOTD, Date, Message, Restrict, IDENT, Name, Show Users, Reboot, Uptime, Prompt

RF Connector N female

Temperature Range Operating: 0°C to +70°C Storage: -55°C to +85°C

Physical Size See outline drawing 092-6343

ECR/ECN # DA	TE REV	APPR / DATE	ECR/ECN #	DATE	REV	APPR / DATE
12/1	0/2009	CLK 12/10/2009				
18137 01/2	2/2010 A	CLK 01/22/2010				
24239 09/0	9/2014 B	TRS 09/09/2014				

Page 2 of 2 JFW FORM E-7-F REV F