SPECIFICATION SHEET JFW MODEL 50PMA-078 TRANSCEIVER TEST SYSTEM

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

Frequency	Range	DC-500	MHz
-----------	-------	--------	-----

Configuration 12 Port Transceiver Test System with 2 RF Hubs

(See block diagram 092-7807)
(all ports are bi-directional)
(limited fan-out configuration)

(the ADMIN password is located on rear panel)

Enclosure Type 19 inch rack mount @ 4RU high

Impedance 50 Ohms nominal

Switch Range J1-J2 (electro-mechanical)

Attenuation Range 0-127 dB in 1 dB steps (electro-mechanical)

Startup/Default States All switches to port J1 at startup (see SWITCH command)

(configurable) All attenuators 127dB at startup (see ATTEN command)

DHCP enabled (see NET command)

4 Ethernet users (see NET USERS command)

Prompts off (see PROMPT command)

VSWR 1.6:1 maximum < 1.4:1 typical

Attenuation Accuracy \pm 0.5 dB (1-31 dB) \pm 1.0 dB (32-127 dB)

Insertion Loss 24.8 dB maximum 22.9 dB typical

RF Input Power 1 Watt average average

Switching Speed 6 milliseconds for Attenuators

20 milliseconds for Switches

(after command is received and processed)
(3 milliseconds typical processing time)

Manual Control 20-Button Keypad and LCD display

(IP Address configurable via keypad) (Net mask configurable via keypad) (Gateway configurable via keypad) (Baud rate configurable via keypad)

Remote Control Ethernet (DHCP, TCP/IP, 10/100, up to 12 users)

RS-232 (up to 115200 Baud)

--CONTINUED--

Page 1 of 2 JFW FORM E-7-F REV F

SPECIFICATION SHEET JFW MODEL 50PMA-078 TRANSCEIVER TEST SYSTEM

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

Remote Commands

Switch Control Commands:

Switch, Set Switch, Read Switch, Set All Switches,

Read All Switches

Attenuator Control Commands:

Atten, Set Attenuator, Read Attenuator, Set All Attenuators, Read All Attenuators, Read All Extended, Fade Attenuator, Variable Attenuator Handover, Block, Set Block, Read Block, Read All Blocks, Fade Block,

Variable Block Handover

System Commands:

Help, Identification, Store, Recall, Pause, Net, Serial, Close, Disconnect, MOTD, Date, Message, Restrict, IDENT, Name, Show Users, Reboot, Uptime,

Prompt

RF Connector

N or SMA female

AC Supply

100-240 VAC @ 47-63 Hz

4 Amp 5x20mm "Slo-Blo" AC fuse Littelfuse #215-004, JFW #025-018

Operating Temperature Range

0°C to +50°C

Physical Size

See outline drawing 092-7806

ECR/ECN	# DATE	REV	APPR / DATE	ECR/ECN # DATE	REV APPR / DATE
	09/11/2013		TRS 09/11/2013		
24239	12/05/2014	A	TRS 12/05/2014		
25671	08/19/2015	В	TRS 08/19/2015		

Page 2 of 2 JFW FORM E-7-F REV F