

SPECIFICATION SHEET

JFW MODEL 50PA-969

PROGRAMMABLE ATTENUATOR ASSEMBLY

JFW Industries, Inc.
Phone: 317-887-1340
sales@jfwindustries.com
www.jfwindustries.com

Frequency Range	698-3000 MHz
Configuration	8 x 8 Handover Test System (see block diagram 092-6869 for attenuator addressing) (all ports are bi-directional) (full fan-out configuration) (the ADMIN password is located on rear panel)
Enclosure Type	19 inch rack mount @ 9RU high (SMA), 10RU high (N)
Impedance	50 Ohms nominal
Attenuation Range	0-95 dB in 1 dB steps
Startup/Default States (configurable)	Maximum attenuation (see ATTEN STARTUP command) DHCP enabled (see NET command) 4 Ethernet users (see NET command) Prompts off (see PROMPT command) All of these default settings can be changed by user. Unit can be configured for up to 12 Ethernet users.
VSWR	1.7:1 maximum < 1.5:1 typical
Insertion Loss	35 dB maximum 30 dB typical @ 698 MHz 34 dB typical @ 3000 MHz
Isolation	50 dB minimum (Input to Input) 50 dB minimum (Output to Output)
Attenuation Accuracy	± 0.50 dB 1-7 dB ± 1.00 dB 8-11 dB ± 1.25 or 3% 12-95 dB (whichever is greater) (guaranteed monotonic)
RF Input Power	+30 dBm average
Switching Speed	1 microsecond typical (after command received and processed) (3 milliseconds typical processing time)
Manual Control	20-Button Keypad and LCD display (IP Address configurable via keypad) (Net mask configurable via keypad) (Gateway configurable via keypad) (Baud rate configurable via keypad)
Remote Control	Ethernet (DHCP, TCP/IP, 10/100, up to 12 users) RS-232 (up to 115200 Baud)

--CONTINUED--

SPECIFICATION SHEET

JFW MODEL 50PA-969

PROGRAMMABLE ATTENUATOR ASSEMBLY

JFW Industries, Inc.
Phone: 317-887-1340
sales@jfwindustries.com
www.jfwindustries.com

Remote Commands

Attenuator Control Commands:

Atten, Set Path, Read Path, Read All Paths, Set Attenuator, Read Attenuator, Set All Attenuators, Read All Attenuators, Read All Extended, Fade Attenuator, Variable Attenuator Handover, Block, Set Block, Read Block, Read All Blocks, Fade Block, Variable Block Handover

System Commands:

Help, Identification, Store, Recall, Pause, Net, Serial, Close, Disconnect, MOTD, Date, Message, Restrict, IDENT, Name, Show Users, Reboot, Uptime, Prompt

RF Connector

N or SMA female

AC Supply


100-240 VAC @ 47-63 Hz
2 Amp 5x20mm "Slo-Blo" AC fuse
Littelfuse #215-002, JFW #025-021

Temperature Range

0°C to +50°C

Outline Drawing Number

092-8131 (50PA-969 SMA)
092-8478 (50PA-969 N)



ECR/ECN #	DATE	REV	APPR / DATE	ECR/ECN #	DATE	REV	APPR / DATE
	09/18/2015		TRS 09/18/2015				
25902	11/09/2015	A	CLK 11/09/2015				