SPECIFICATION SHEET JFW MODEL 50PMA-076 TRANSCEIVER TEST SYSTEM

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

Frequency Range 2-6 GHz

Configuration 8 Port Tranceiver Test System

(see block diagram 092-5910 for attenuator addressing)

(all ports are bi-directional)

(full fan-out i.e. every path has its own attenuator)

(the ADMIN password is located on rear panel)

Enclosure Type 19 inch rack mount @ 4RU high

Impedance 50 Ohms nominal

Attenuation Range 0-95 dB in 1 dB steps

Startup/Default States Maximum attenuation (see ATTEN STARTUP command)

(configurable) DHCP enabled (see NET command)

4 Ethernet users (see NET USERS command)

Prompts off (see PROMPT command)

VSWR 1.7:1 maximum

1.6:1 typical

Insertion Loss 37.0 dB maximum

31.0 dB typical @ 2 GHz 35.0 dB typical @ 6 GHz

Attenuation Accuracy \pm 0.50 dB 1-3 dB

± 1.00 dB 4-11 dB ± 1.25 or 4% 12-95 dB (whichever is greater) (guaranteed monotonic)

Power Divider Isolation 21 dB minimum

RF Input Power 1 Watt average

Switching Speed 1 microsecond typical

(after command is received and processed)
(3 milliseconds typical processing time)

AC Supply 100-240 VAC @ 47-63 Hz

4 Amp 5x20mm "Slo-Blo" AC fuse Littelfuse #215-004, JFW #025-018

Manual Control 20-Button Keypad and LCD display

(IP Address configurable via keypad) (Net mask configurable via keypad) (Gateway configurable via keypad) (Baud rate configurable via keypad)

Remote Control Ethernet (DHCP, TCP/IP, 10/100, up to 12 users)

RS-232 (up to 115200 Baud)

--CONTINUED--

Page 1 of 2 JFW FORM E-7-F REV F

SPECIFICATION SHEET JFW MODEL 50PMA-076 TRANSCEIVER TEST SYSTEM

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

Remote Commands Attenuator Control Commands:

Atten, Set Path, Read Path, Read All Paths, Set Attenuator, Read Attenuator, Set All Attenuators, Read All Attenuators, Read All Extended, Fade Attenuator, Variable Attenuator Handover, Block, Set Block, Read Block, Read All Blocks, Fade Block, Variable Block Handover

System Commands:

Help, Identification, Store, Recall, Pause, Net, Serial, Close, Disconnect, MOTD, Date, Message, Restrict, IDENT, Name, Show Users, Reboot, Uptime, Prompt

RF Connector SMA female

Temperature Range Operating: 0°C to +70°C Storage: -55°C to +85°C

Physical Size See outline drawing 092-7357

ECR/ECN # DATE	REV APPR / DATE	ECR/ECN # DATE	REV APPR / DATE
06/12/2013	BAC 06/12/2013		
24239 09/09/2014	A TRS 09/09/2014		

Page 2 of 2 JFW FORM E-7-F REV F