#### SPECIFICATION SHEET

### JFW MODEL 50MS-313

## 4x4 NON-BLOCKING SOLID STATE MATRIX SWITCH

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

Frequency Range 700-3000 MHz

Configuration 4 x 4 Non-Blocking Solid-State Matrix

(see block diagram 092-7494)

(Unused input ports are self-terminating) (Unused output ports are self-terminating)

(all ports are bi-directional)

(the ADMIN password is located on rear panel)

Startup/Default States

(configurable)

All ports off at startup (see MATRIX command)

DHCP enabled (see NET command) 4 Ethernet users (see NET command) Prompts off (see PROMPT command)

All of these default settings can be changed by user. Unit can be configured for up to 12 Ethernet users.

Enclosure Type 19 inch rack mount @ 3RU high

Impedance 50 Ohms nominal

VSWR 1.5:1 typical / 1.7:1 maximum

Insertion Loss 10 dB nominal @ 700MHz 12 dB nominal @ 3000MHz

Isolation Output to Output - 80 dB typical

(Set to Diff INs) - 60 dB minimum

Output to Output - 28 dB typical (Set to Same IN) - 20 dB minimum

Input to Output - 80 dB typical (Path OFF) - 60 dB minimum

Input to Input - 80 dB typical - 60 dB minimum

RF Input Power +30 dBm maximum

Switching Speed 10 microseconds

(after command is received and processed)
(3 milliseconds typical processing time)

Manual Control 20-Button Keypad and LCD display

(IP Address configurable via keypad) (Net mask configurable via keypad) (Gateway configurable via keypad) (Baud rate configurable via keypad)

Remote Control Ethernet (DHCP, TCP/IP, 10/100, up to 12 users)

RS-232 (up to 115200 Baud)

### --CONTINUED--

Page 1 of 2 JFW FORM E-7-F REV F

## SPECIFICATION SHEET

## JFW MODEL 50MS-313

# 4x4 NON-BLOCKING SOLID STATE MATRIX SWITCH

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

Remote Commands Matrix Commands:

Matrix, Set Input, Set Output, Read Input, Read

Output, Read All Inputs, Read All Outputs, Read Matrix

Paths

System Commands:

Help, Identification, Store, Recall, Pause, Net,

Serial, Close, Disconnect, MOTD, Date,

Message, Restrict, IDENT, Name, Show Users, Reboot,

Uptime, Prompt

RF Connector N female

AC Supply 100-240 VAC @ 47-63 Hz

2 Amp 5x20mm "Slo-Blo" AC fuse Littelfuse #215-002, JFW #025-021

Temperature Ranges Operating: 0°C to +70°C

Storage: -55°C to +85°C

Physical Size See outline drawing 092-6835

ECR/ECN	# DATE	REV	APPR / DATE	ECR/ECN #	DATE	REV	APPR / DATE
	10/23/2012		BAC 10/23/2012				
24239	04/28/2015	A	BAC 04/28/2015				

Page 2 of 2 JFW FORM E-7-F REV F