



(BNC Panel-2 Hole Turret Terminal)




**PART #**  
BNC-4000-1001

(BNC 4 Hole Jack Solder Pot)




**PART #**  
BNC-4000-1004

(BNC Panel Jack-4 Hole Cable-UT 085)




**PART #**  
BNC-4000-1002

(BNC B/Head Rear Mount Jack Solder Pot)




**PART #**  
BNC-4000-1005

(BNC Panel Jack-4 Hole Cable-UT 141)



**PART #**  
BNC-4000-1003


(BNC B/Head Rear Mount Jack Cable-UT 141)



**PART #**  
BNC-4000-1006




**(BNC Straight Plug  
Cable-RG 58)**




**PART #**  
BNC-4000-2001

**(BNC Straight Jack  
Cable-RG 58, 141)**




**PART #**  
BNC-4000-1007

**(BNC Straight Plug  
Cable-RG 400, 223)**




**PART #**  
BNC-4000-2002

**(BNC R/Angle Plug  
Cable-RG 178)**




**PART #**  
BNC-4000-2004

**(BNC Straight Plug  
Cable-RG 214)**



**PART #**  
BNC-4000-2003

**(BNC R/Angle Plug  
Cable-RG 400, 223)**



**PART #**  
BNC-4000-2005