SPECIFICATION SHEET JFW MODEL 50PA-764 HANDOVER TEST SYSTEM

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

Frequency Range 700-3000 MHz

Configuration 12 x 5 Handover Test System

(see block diagram 092-7565 for attenuator addressing)

(all ports are bi-directional)

(full fan-out i.e. every path has its own attenuator)

(the ADMIN password is located on rear panel)

Enclosure Type 19 inch rack mount @ 13RU high

Impedance 50 Ohms nominal

Attenuation Range 0-127 dB in 1 dB steps

Startup/Default States Maximum attenuation (see ATTEN STARTUP command)

(configurable) DHCP enabled (see NET command)

4 Ethernet users (see NET USERS command)

Prompts off (see PROMPT command)

VSWR 1.5:1 typical

1.8:1 maximum

Insertion Loss 35.5 dB typical

36.5 dB maximum

Attenuation Accuracy \pm 0.50 dB or 2% typical

 \pm 0.75 dB or 2% maximum (whichever is greater)

(guaranteed monotonic)

Power Divider Isolation 20 dB minimum

RF Input Power 1 Watt average

Switching Speed 5 microseconds typical

(after command is received and processed)
(3 milliseconds typical processing time)

AC Supply 100-240 VAC @ 47-63 Hz

4 Amp 5x20mm "Slo-Blo" AC fuse Littelfuse #215-004, JFW #025-018

Manual Control 20-Button Keypad and LCD display

(IP Address configurable via keypad) (Net mask configurable via keypad) (Gateway configurable via keypad) (Baud rate configurable via keypad)

Remote Control Ethernet (DHCP, TCP/IP, 10/100, up to 12 users)

RS-232 (up to 115200 Baud)

--CONTINUED--

Page 1 of 2 JFW FORM E-7-F REV F

SPECIFICATION SHEET JFW MODEL 50PA-764 HANDOVER TEST SYSTEM

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

Remote Commands

Attenuator Control Commands:
Atten, Set Path, Read Path, Read All Paths, Set
Attenuator, Read Attenuator, Set All Attenuators, Read
All Attenuators, Read All Extended, Fade Attenuator,
Variable Attenuator Handover, Block, Set Block, Read
Block, Read All Blocks, Fade Block, Variable Block
Handover

System Commands:

Help, Identification, Store, Recall, Pause, Net, Serial, Close, Disconnect, MOTD, Date, Message, Restrict, IDENT, Name, Show Users, Reboot, Uptime, Prompt

RF Connector

N or SMA female

Temperature Range

 $0^{\circ}C$ to $+50^{\circ}C$

Physical Size

See outline drawing 092-7564

ECR/ECN # DATE	REV	APPR / DATE	ECR/ECN #	DATE	REV	APPR / DATE
01/09/2013		TRS 01/09/2013				
24239 09/09/2014	A	TRS 09/09/2014				

Page 2 of 2 JFW FORM E-7-F REV F