

SPECIFICATION SHEET

JFW MODEL 50PA-125-XX

PROGRAMMABLE ATTENUATOR ASSEMBLY

JFW Industries, Inc.
Phone: 317-887-1340
sales@jfwindustries.com
www.jfwindustries.com

| | |
|--|---|
| Frequency Range | 30-3000 MHz |
| Attenuation Range | 0-95 dB in 1 dB steps |
| Configuration | Individually controlled solid-state programmable attenuators. Number of attenuators can be selected from 1 to 8 attenuators. |
| Enclosure Type | 19 inch rack mount 2RU high (for 1-8 attenuators) |
| Impedance | 50 Ohms nominal |
| Startup/Default States (configurable) | Maximum attenuation (see ATTEN command) DHCP enabled (see NET command) 4 Ethernet users (see NET command) Prompts off (see PROMPT command) All of these default settings can be changed by user. Unit can be configured for up to 12 Ethernet users. |
| VSWR | 2.2:1 maximum 30-800 MHz 1.6:1 maximum 800-3000 MHz |
| Attenuation Accuracy | ± 0.50 dB 1-7 dB ± 1.00 dB 8-11 dB ± 1.25 or 3% 12-95 dB (whichever is greater) (guaranteed monotonic) |
| Insertion Loss | 6.5 dB maximum 6.0 dB typical |
| RF Input Power | +20 dBm average +25 dBm no damage |
| Switching Speed | 1 microsecond typical (after command is received and processed) (3 milliseconds typical processing time) |
| Manual Control | 20-Button Keypad and LCD display (IP Address configurable via keypad) (Net mask configurable via keypad) (Gateway configurable via keypad) (Baud rate configurable via keypad) |
| Remote Control | Ethernet (DHCP, TCP/IP, 10/100, up to 12 users) RS-232 (up to 115200 Baud) |

--CONTINUED--

SPECIFICATION SHEET
JFW MODEL 50PA-125-XX
PROGRAMMABLE ATTENUATOR ASSEMBLY

JFW Industries, Inc.
 Phone: 317-887-1340
 sales@jfwindustries.com
 www.jfwindustries.com

Remote Commands

Attenuator Control Commands:

Atten, Set Attenuator, Read Attenuator, Set All Attenuators, Read All Attenuators, Read All Extended, Fade Attenuator, Variable Attenuator Handover, Block, Set Block, Read Block, Read All Blocks, Fade Block, Variable Block Handover

System Commands:

Help, Identification, Store, Recall, Pause, Net, Serial, Close, Disconnect, MOTD, Date, Message, Restrict, IDENT, Name, Show Users, Reboot, Uptime, Prompt

RF Connector

SMA or N female

Operating Temperature Range

0°C to +50°C

AC Supply

100-240 VAC @ 47-63 Hz

Outline Drawing Numbers

092-8261 (N female, 1-8 attenuators)
 092-8262 (SMA female, 1-8 attenuators)

Example Model Numbers

50PA-125-01 SMA (1 attenuator)
 50PA-125-02 SMA (2 attenuators)
 50PA-125-03 SMA (3 attenuators)
 50PA-125-04 SMA (4 attenuators)
 50PA-125-05 SMA (5 attenuators)
 50PA-125-06 SMA (6 attenuators)
 50PA-125-07 SMA (7 attenuators)
 50PA-125-08 SMA (8 attenuators)
 50PA-125-01 N (1 attenuator)
 50PA-125-08 N (8 attenuators)

| ECR/ECN # | DATE | REV | APPR / DATE | ECR/ECN # | DATE | REV | APPR / DATE |
|-----------|------------|-----|----------------|-----------|------|-----|-------------|
| | 06/01/2015 | | TRS 06/01/2015 | | | | |