SPECIFICATION SHEET

JFW MODEL 50PA-941 PROGRAMMABLE ATTENUATOR ASSEMBLY

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

Frequency Range	700-6000 MHz		
Configuration	Dual 8 x 1 LC Handover Test System (see block diagram 092-8322 for attenuator addressing) (all ports are bi-directional) (limited fan-out configuration) (the ADMIN password is located on rear panel)		
Enclosure Type	19 inch rack mount @ 3RU high		
Impedance	50 Ohms nominal		
Attenuation Range	0-95 dB in 1 dB steps		
Startup/Default States (configurable)	Maximum attenuation (see ATTEN command) DHCP enabled (see NET command) 4 Ethernet users (see NET command) Prompts off (see PROMPT command)		
VSWR	1.7:1 maximum < 1.5:1 typical (Inputs) < 1.6:1 typical (J1)		
Insertion Loss	26.6 dB maximum 25.8 dB typical		
Power Divider Isolation	20 dB minimum		
Attenuation Accuracy	<pre>± 0.50 dB 1-3 dB ± 0.75 dB 4-7 dB ± 1.00 dB 8-11 dB ± 1.25 dB or 4% 12-95 dB (whichever is greater) (guaranteed monotonic)</pre>		
RF Input Power	+23 dBm average		
Switching Speed	1 microsecond typical (after command is received and processed) (3 milliseconds typical processing time)		
Manual Control	20-Button Keypad and LCD display (IP Address configurable via keypad) (Net mask configurable via keypad) (Gateway configurable via keypad) (Baud rate configurable via keypad)		
Remote Control	Ethernet (DHCP, TCP/IP, 10/100, up to 12 users) RS-232 (up to 115200 Baud)		

--CONTINUED--

SPECIFICATION SHEET

JFW MODEL 50PA-941 PROGRAMMABLE ATTENUATOR ASSEMBLY

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

Remote Commands	Attenuator Control Commands: Atten, Set Attenuator, Read Attenuator, Set All Attenuators, Read All Attenuators, Read All Extended, Fade Attenuator, Variable Attenuator Handover, Block, Set Block, Read Block, Read All Blocks, Fade Block, Variable Block Handover	
	System Commands: Help, Identification, Store, Recall, Pause, Net, Serial, Close, Disconnect, MOTD, Date, Message, Restrict, IDENT, Name, Show Users, Reboot, Uptime, Prompt	
RF Connector	N or SMA female	
AC Supply	100-240 VAC @ 47-63 Hz 2 Amp 5x20mm "Slo-Blo" AC fuse Littelfuse #215-002, JFW #025-021	
Temperature Range	0°C to +50°C	
Physical Size	See outline drawing 092-8321	

ECR/ECN # DATE	REV APPR / DATE	ECR/ECN # DATE	REV APPR / DATE	
05/21/2015	TRS 05/21/2015			
		_		
f 2	JFW FORM E-7-F REV F			