SPECIFICATION SHEET JFW MODEL 50PMA-041 TRANSCEIVER TEST SYSTEM	JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com
Frequency Range	30-3000 MHz
Configuration	32 Port Transceiver Test System (see block diagram 092-6888 for attenuator addressing) (all ports are bi-directional) (full fan-out i.e. every path has its own attenuator) (the ADMIN password is located on rear panel)
Enclosure Type	23 inch rack cabinet w/ doors on front and rear of cabinet. See outline drawing 092-6887 for cabinet dimensions.
Impedance	50 Ohms nominal
Attenuation Range	0-63 dB in 1 dB steps
VSWR	1.8:1 maximum
Attenuation Accuracy (guaranteed monotonic)	± 0.70 dB 1-7 dB ± 1.00 dB 8-11 dB ± 1.25 dB or 4% 12-63 dB (whichever is greater)
Insertion Loss	56 dB maximum 53 dB typical @ 3 GHz
Power Divider Isolation	20 dB minimum
RF Input Power	1 Watt average
Switching Speed	2 microseconds (after command is received and processed) (3 milliseconds typial processing time)
AC Supply	100-240 VAC @ 47-63 Hz 4 Amp 5x20mm "Slo-Blo" AC fuse Littelfuse #215-004, JFW #025-018
Remote Control	Ethernet (DHCP, TCP/IP, 10/100, up to 12 users) RS-232 (up to 115200 Baud)

--CONTINUED--

SPECIFICATION SHEET JFW MODEL 50PMA-041 TRANSCEIVER TEST SYSTEM	JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com
Remote Commands	Attenuator Control Commands: Atten, Set Path, Read Path, Read All Paths, Set Attenuator, Read Attenuator, Set All Attenuators, Read All Attenuators, Read All Extended, Fade Attenuator, Variable Attenuator Handover, Block, Set Block, Read Block, Read All Blocks, Fade Block, Variable Block Handover
	System Commands: Help, Identification, Store, Recall, Pause, Net, Serial, Close, Disconnect, MOTD, Date, Message, Restrict, IDENT, Name, Show Users, Reboot, Uptime, Prompt
RF Connector	SMA female
Operating Temperature Range	0°C to +50°C
Physical Size	See outline drawing 092-6887